

Tech Note

The Sony DFP-D3000 requires D-Subminiature connectors with metric jack screws. A kit of mating connectors is available.

Product: DFP-D3000.
S/N: All units.
Document: **TN99052301**, CC
Summary: The DFP-D3000 requires metric D-Sub connectors. A kit of these connectors is available. The Sony Part Number is STK-2202.

The Sony DFP-D3000 cinema processor uses 9-pin and 25-pin D-Subminiature connectors (commonly referred to as DB9 and DB25 D-Subs) which have metric jack screws. These jack screws are similar, but not identical, to the ANSI standard jack screws which are commonly used on D-Sub connectors in the USA. There is the potential for damage to threads if the wrong type of jack screws are used and these screw thread standards become intermixed. At the same time, Sony recommends using jack screws to secure the mating connectors to the DFP-D3000.

Sony Cinema Products provides a kit of the correct type of connectors at no charge, for each DFP-3000. This kit contains the electrical connectors of the proper type and gender, connector shells, and both ANSI and metric jack screws for all connectors. The part number for this kit is STK-2202.

Contents	Part Number
D-Sub 25s, Female connector (x2) shell (x2)	DNT25SZ CT25M
D-Sub 9p, Male connector (x3) shell (x3)	DNT9PZ CT9M
D-Sub 25p, Male connector (x2) shell (x2)	DNT25PZ CT25M
D-Sub 37p, Male connector (x1) shell (x1)	DNT37PZ CT37M

Additional quantities of these connectors can be obtained from the manufacturer; be sure to specifically request metric jack screws. Please contact

Atwater Electronics
P.O. Box 10127
Burbank CA 91510
+1 (818) 841-9050
www.atwaterelex.com